



## Mini Socket - Round: Installation Instructions

**Step 1:** Select a sturdy location in the lining, coaming, dash or other surface of your marine-craft, vehicle or aircraft, to drill a 28mm hole that can be accessed from both sides

**Step 2:** Drill a 28mm hole. (Carbon-tipped 28mm hole saws are available from the Tallon Online Store under “Mini Socket Installation Pack”)

**Step 3:** The Strengthening Washer Plate can be used to stop rotation if required. To install this, drill 2 x 3mm holes using the washer itself as a drill template. The washer can be used on either side of the 28mm hole depending on access. Screw the plate on if required.

**Step 4:** Insert the Tallon Mini Socket to into the 28mm hole and screw on the back nut being careful not to cross thread or over-tighten as this may adversely affect performance of the unit.

**Step 5:** To mount an accessory, insert your Stainless Tallon RAM Connector at a 45° downward angle; level the connector when fully inserted then pull firmly outwards. Press down on the Tallon Locking Tab to lock in place.

Enjoy the use of your Tallon Mini Socket! See the TallonTV Channel on YouTube for video demonstrations.

